


FENIX - 400



000005	O ring	100451	Sear
000006	Compressor spring	100458	Hook support
000007	Compressor ball	000461	Hook support hinge pin
100008	Lateral washer	100433	Support pin 6x30,2
000293	Lever washer	100434	Main spring support screw
100410	Lever	000026	Toothed washer
100011	Lever pin	100027	Lateral screw
100012	Cocking cam	100529	Trigger guard front screw
100013	Hinge pin screw	000430	Trigger guard
100014	Set screw	100431	Trigger guard rear screw
100442	Safety	000419	Main spring front guide
000317	Piston seal	000420	Main spring
200418	Piston	C0P40015	Tube
300453	Trigger assembly	C4P4001	Barrel (4,5)
200470	Trigger group	C5P4001	Barrel (5,5)
000454	Presión adjusting spring	200402	Front sight
000457	Presión adjusting screw	000402_3	Front sight cover
200440	Main spring support	200404	Rear sight
000446	Hook pin	B00425	Butt stock
100447	Trigger hook	B00425_AS	Adjustable butt stock
000449	Trigger hook spring	W00425	Walnut stock
100450	Sear pin 3x10,3	W00425_AS	Adjustable walnut stock